



Installation Instructions: ADA Signage

Find the location:

Measure 60" up from the finish floor on the latch side of the door. This is where the centerline of the sign should be.

Make sure the sign is at least 3" away from the door jamb, to make sure a person reading it is away from the swing of the door.

Note: This location is based on the federal ADA law. Check your state and local laws to see if you need to match a different standard.

Your installation is now complete.